




# Technical Summary

## M Pro Series - VESA


### Face Down Mount 100/200/300/400

EAN: 7350105215902




#### COMPONENT CHECKLIST


Item	Name	QTY
A1	M5 x 15mm ScREW	4
A2	M6 x 15mm ScREW	4
A3	M8 x 25mm ScREW	4
A4	Ø16x Ø6.2x1.5 Washer	4
A5	M8 x 45mm ScREW	4
A6	Ø16x Ø8.2x1.5 Washer	4
A7	Ø13x Ø8.2x13 Washer	4
B1	M6 x 16mm ScREW	2
B2	M8	4
B3	Ø16x Ø8.2x1.5 Washer	4
B4	Lag bolt	4
B5	Anchor	4
B6	Open-end wrench	1
AA	Wall plate	1
BB	Adapter plate	1
CC	Extension bars	1



AA




BB



CC



A1 A2 A3 A4 A5 A6 A7





B1 B2 B3 B4 B5 B6




# INSTALLATION INSTRUCTION

1 -a





1 -b




2 -a MOUNTING ON CEILING


(A-1) Wood ceiling




(A-2) Concrete ceiling




(A-3) Attaching the TV to the VESA Plate  
VESA 100×100~200×200



(A-4) Attaching the TV to the VESA Plate  
VESA 200×200~400×400




(A-5) Hanging TV On The ceiling Mount Arms




B1  
Security screw

**2** -b MOUNTING ON WALL


(B-1) Wood studs




(B-2) Concrete wall





(B-3) Attaching the TV to the VESA Plate  
VESA 100×100~200×200




(B-4) Attaching the TV to the VESA Plate  
VESA 200×200~400×400




# (B-5) Hanging TV On The Wall Mount Arms



5.1



5.2



5.3

